


ELMO-document camera set-up with an AV or base computer and LCD projector

What do you need?


- LCD Projector 
- AV or Base Computer 
- 2 Additional RGB Cables 
- USB Cable 

DRAFT August 2011

ELMO-document camera set-up with an AV or base computer and LCD projector (cont)




ELMO



LCD Projector


Connect from RGB-out on the ELMO to Computer 1 IN on the LCD projector. Connect from Computer 2 IN/OUT on the LCD projector to the monitor on the computer.




Monitor

DRAFT August 2011


ELMO-document camera set-up with an AV or base computer and LCD projector



AV/Video Computer



Base Computer




ELMO


Connect from the computer to RGB-in on the ELMO using an RGB cable. If using an AV splitter connect to #2. Alternatively, you may need an DV/RGB adapter.

DRAFT August 2011

ELMO-document camera set-up with an AV or base computer and LCD projector (cont)



ELMO



Computer

Connect the USB cable from the ELMO to the computer. Once the USB connection is made, a Hardware Wizard will appear. Accept the default settings. Click Next and Finish. The Hardware Wizard needs to be done for the Image Mate software to recognize the ELMO. The wizard will run using the Local Admin login or your AD login.

DRAFT August 2011