


Getting started with a mobile hotspot

1. To turn it on, press and hold the power button  on the front of the device, until the display on top shows "Welcome".




2. When the display shows the T-Mobile logo, the hotspot is ready to connect.




3. The charging cable is in the box under the tray holding the mobile hotspot. The hotspot can be used with or without the cable plugged in, but will need to be charged from time to time. The remaining battery life is shown in the display. Press the power button to wake the display if it is off.

Connect from a Chromebook


1. In the lower right corner, click the time.




2. Click **Not Connected**.




3. Click **MCPS-MiFi**.




4. Enter the password **sm0bm1f1** and click **Connect**.




5. The **MCPS-MiFi** network will then show as connected in the network list.




6. Sign in to the Chromebook with your MCPS Google username and password.
a. For staff, remember to use periods instead of underscores.




- b. For students, your username is your student ID number.




Connect from a Windows 10 computer

1. Click the network icon  in the lower right corner of the screen, next to the time.
 - a. The icon may also look like .
2. Click **MCPS-MiFi** in the list of available networks.



3. Ensure that **Connect automatically** is checked, then click **Connect**.



4. Enter the password **sm0bm1f1** and click **Next**.



5. Your computer is now connected to the Internet.